

Detail of Trimless Fire Extinguisher Cabinets

TRIMLESS CABINETS FOR NON RATED WALLS - INSTALL OVER DRYWALL OR UNDER PLASTER

**FLANGE FOR 5/8" DRYWALL
WITH DRYWALL BEAD
1034WBV10**

**FLANGE FOR 3/4" PLASTER
WITH PLASTER STOP
1034PWW10**

Distributed by: [Safety Emporium](http://www.safetyemporium.com) Ph: (866) 326-5412 toll-free
 PO Box 1003 Fax: (856) 553-6154
 Blackwood, NJ 08012 esupport@safetyemporium.com
www.safetyemporium.com

TRIMLESS CABINETS FOR FIRE-RATED WALLS - INSTALL BETWEEN LAYERS OF DRYWALL OR PLASTER

**FLANGE FOR PLASTER RECESSED 3/4" FROM
CABINET FACE - INSTALL 1ST LAYER OF
SUBSTRATE, THEN CABINET, THEN APPLY
METAL LATH AND PLASTER 1034HV10**

**FLANGE FOR 5/8" DRYWALL RECESSED 5/8" FROM CABINET FACE
INSTALL 1ST LAYER OF DRYWALL, THEN CABINET,
THEN FINAL LAYER OF DRYWALL
1034DV10**

ACTIVAR INC.
CONSTRUCTION PRODUCTS GROUP

4/25/16 © Activar Construction Products 2016

