



Distillation System Connection Diagram




Vacuum Pump	Vacuum Controller
SCI410	SCI100VC
1	Cooling water inlet
2	Cooling water outlet
3	Vacuum Port
4	Pump interface
5	Load interface
6	Vacuum suction port
7	Circulator water inlet
8	Circulator water outlet
9	Inert Gas Inlet
10	Pump Air Vent



Rotary Evaporator
 SCI100-S


Low Temp. Circulator
 SCP5-20

Distributed by:
 Safety Emporium
 PO Box 1003
 Blackwood, NJ 08012
 Pn: (866) 326-5412 toll-free
 Fax: (856) 563-6154
 esupport@safetyemporium.com
 www.safetyemporium.com





Distillation System Connection Diagram (without vacuum controller)


Distributed by:
Safety Emporium
P.O. Box 1003
Blackwood, NJ 08012
Ph: (866) 326-5412 toll-free
Fax: (856) 553-6154
esupport@safetyemporium.com
www.safetyemporium.com



①	Cooling water inlet
②	Cooling water outlet
③	Vacuum Port
④	Circulator water outlet
⑤	Circulator water inlet
⑥	Vacuum suction port
⑦	Pump Air Vent



SCIP5-20 connecting with 2 units rotary evaporators



Low Temp. Circulator
SCIP5-20

Rotary Evaporator
SCI100-Pro

Rotary Evaporator
SCI100-S

①	RE100-Pro cooling water inlet
②	RE100-Pro cooling water outlet
③	RE100-S cooling water outlet
④	RE100-S cooling water inlet
⑤	Circulator water outlet
⑥	Circulator water inlet
⑦	RE100-Pro vacuum port
⑧	RE100-S vacuum port

